ONE SHOT CONFETTI MACHINE

USER MANUAL

AC220V-240V ☑

AC100V-120V ☐

Unpacking Inspection

Please inspect the box whether it is in good condition before unpacking it. If find the box is broken in transport please inform the transport company in time and keep the broken box as proof so that we can claim to transport company for compensation.

The packing list as follows:

1. 1 pc one shot confetti machine
2. 1 pc power supply cable
3. 1 pc user manual

Production Introduction

This confetti machine is our unique celebration effect machine. Through the DMX control, shoot the electric confetti which put in the machine to create a cheerful celebration scene atmosphere. If multiple machines are used together, the effect will be better. Particularly suitable for new work conference, stage effect, the opening ceremony, wedding occasions etc.

Product specifications and parameters:

Size: L17×W14×H18cm

Weight: 4KG

Power: 20W

Voltage: AC220V / 110 v,50/60Hz

Features: adopt direct power control, DMX512 control and easy to operation

Installation

1.Connect power cable of the confetti machine to power supply and ensure reliable connection.

2.Put the electronic confetti cannons into the machine's barrel and fix the cannons by turning the handle bolt.

4.Before connecting confetti cannon shooting connector, turn on power to test the indicator lamps work normally beside the shooting connector socket.

5.Put the power cable of the electronic confetti into the socket of the machine, connection complete.



Digital Dial Code Operation Method

1.Press "set" to enter setup mode

2.Green light crush out after press "set" into, the digital tube flash

3.Key “↑” is “add”.key “↓” is”reduction”,Long press the “↑” or “↓” ,the figures will add /reduction quickly.

4.The digital tube first numer is “1”,the last one is “511”,in the position of number “1”,press ”↓”,the next number is “511”.

5.Press "set" to confirm after Dialing code to the number of you want .

6.After confirmation, this machine haven't access to the signal if the green light still lighting .

It can work if flashing shows that this machine have signal.



Operation Method

Install the confetti machine in accordance with the "installation".

According to the practical needs, connected confetti machine with power supply and turn on power switch to shoot confetti.

Please turn off power switch as soon as finish shooting!

The electrifying time of confetti machine shall not exceed 3 seconds!

Notice:

In order to ensure reliable connection, after installation, do not connect confetti connector with the machine, turn on power to inspect if the indicator lamps light on, to ensure reliable shooting.

Troubles Shooting

Simple Trouble Shooting

1.After turn on power switch, if the indicator lamps don't light on, please inspect if the power supply voltage is in accordance with the requirements of the power socket, inspect if the power socket fuse work well.